

ALASKA PINE & CELLULOSE  
MAHATTA RIVER

PACIFIC TRUCK & TRAILER LTD. Truck # 2051

MODEL 4640-A

SERIAL T-860-114

DELIVERED

D.R.

ENGINE NRT-6B

Serial 221328

SNW 36326

Bellhousing 10486-1

Flywheel 20462

Fuel Pump 6NR109052TC2100

Oil Pan 117588

Exhaust Man'd 117157, 117157, 117911

Fan 28 DIA. 20217-1

Fan Mounting 21 5/8 C. to C.

Fan Belts S-3161 (2)

Turbo - Model T-690 Part No. BW47802 Serial 6648

Air Cleaner Model G 140G2 Series 159

Lub. Oil Filter 750 L

Front Eng. Support EM 32055 33231 (Top) 101740 (Bottom)

ELECTRICAL EQUIPMENT 24 Volt System

Batteries SC-21-# (2)

Generator 1106855 Serial 23546

Starter 1113708 Serial 18744

Voltage Reg. 1118737C

Key SW. 370-E

Push Button SW. 66501

Headlight SW. DS-40X

Fuel SW. 7116

Terminal Block WTB-6

Headlight 903-45

Spotlight 497-90

ELECTRICAL EQUIP'T. (Cont'd)

Warning Light 313504-431

Fuses (5) CM-10 (1) CM-60

INSTRUMENTS

Ammeter 440158

Fuel Gauge 358-E

Fuel Pressure Gauge 444246

Lub. Oil Press. 360-A

Oil Temp. 361-A

Water Temp. 361-B

Tachometer 557-JN

Speedometer 564-S

Air Gauge 444228

Speedo. Cable 65600X164"

Core and clutch ass'y. 65659  
Case and Ferrule Assy'. 34179

Tach. Cable 96300X50"

Core and clutch assy! 65659  
Case and ferrule ass'y. 416618

Speedometer Gears Drive 447077

Driven 70509

Sleeve 403170

Bushing 34671

Speedometer Adapter 777-B-9183

FUEL SYSTEM

Tank FT-10 Bracket - FTS-9A

Cap 60-297

Filler Neck ND-1299

Location L.H. side under running board

Fuel Gauge 358-E

Resistor 421090 Unit 380-B-18

Primer Cummins

Idling Control 3-A-580

Emergency Stop 105204

SLUTCH 15 1/2" 2 plate spicer

CLUTCH Cont'd.

Pilot Bearing 6306-Z

Throwout Bearing 550353

TRANSMISSION 8241 Serial T-166355 SEM 3801 259

Bellhousing 102-C-445

Drive Gear 82-35-1

Aux. Control 001463

AUX. TRANSMISSION 8031-C Serial 148050 SEM 37817

Front Trunnion 70-410-2

EXHAUST Special - Front R.H. side of cab.

STEERING Gemmer 500 8X-58112-A

Tube Length 54 7/8

Wheel 27" DIA

Low Mount Pump V-210 -8-10-12 LH

Cylinder 86-277 Belts 101 or 48

HYD. PUMP BRACKET BU-9 Pump bracket to front engine cross member BV-12

Cylinder to draglink Bracket BV-10 Frame to Cyl'd. Brk't BV-13

Droparm E-102294

Dragling CT-28D-626 27 1/2 centres

PROPELLOR SHAFT 1700, 1800, 1700

Front Joints 10271-40SF Flange Yoke 6-2-319

Front Companion Flange 6-1-1731

Rear companion Flange 6-1-1481

LENGTH F. TO F. 33 Tube Size 3 1/2 x 145 wall

CENTRE JOINTS 10427-27SF Flange yoke front 6 1/2-2-89

Front Companion Flange 6 1/2-1-301

Rear Companion Flange 6 1/2-1-211

Length F. to F. 51 Tube size 3 1/2 x 188 wall

Rear joints 10427-27 SF End Yoke 6-4-1211

Length C.C. Journals 27 3/8

Propeller Shaft Con't.

Tube size 3 1/2 x 156 wall

RADIATOR AR-7A

Core SK-540406A

Size 4 1/2 x 30 x 36

Shutter SB-7A

Shroud SRF-1S

Cap 250158

Neck 676-P-20

Gasket 846732

GR-9

Mounting parts (2) PR-4 rubber, St-15 Stud  
(2) PR-1 rubber, RCW-1 Rubber cup (4)

Ornament NPX-5

Connections WC-2 top WC-9 bottom, WC-1 (Engine Top)

Shutterstat Z-1211

Air Cylinder Z-1108

Filter Z-1623

PARKING BRAKE 16" Tru-stop - 65-D60550 Disc. 65-D-1800

FRONT AXLE SFD-4640-HPX-32

Forward Axle D4640 HFP-X32

Serial F 696016

Rear axle D 4640 HRF-X39

Serial F 696112

Ratio 10.16

Track 74 1/8

Brakes 18 x 7

Lining Kit 2000-U-21

Brake Drum A 3219-K-2065

Hub A-333-D-999

Capnuts inner 49414 - R.H.

49415 - L.H.

Stud 63342 L.H. 63341 R.H.

Capnuts outer 49416 - R.H.

49417 - L.H.

Axle Shaft 3202-N-2536 (Short) 3202-P-2539 (Long)

Camshaft

L.H. Forward R.H. Rear 2210-P-2980

R.H. Forward L.H. Rear 2210-Q-2981

Brake chambers Type 30 225254

Slack Adjusters 222821

Rear Axle Cont'd.

Tires 1200-24 16 ply Seiberling Traction Lug  
Wheels 49160 Rock service Logger Type.

FRAME 9" x 3 1/4 x 1/2 x 360", 8 1/2 x 3 x 1/4 x 330

BRAKE SYSTEM

Valves Brake 228048  
Hand 224491 2-way check 217698  
Safety 205105  
Exhaust check 223869 Horn WH-7000-5  
Quick release 205000  
Booster protection valve - BCP-56  
Governor 224333  
Low pressure Ind. 223578  
Compressor L.H. 228789 Serial 2I 1058  
R.H. 228306 Serial IA 31 58  
Reservoir 221394 Drain cock 215310  
Williams safety valve ES-60 A.B.C. kit  
Chambers and slack adjusters - See axle parts.

FRONT SPRINGS. S-15

Spring pin SF-60 Bushing B-20-33  
U Bolts UB-15 B Shackle - SS-1  
Spring Pad TSP-13

REAR SPRINGS S-12D

U Bolt UB-12B  
Spring S-12D  
Spring Pad TSP-2

BODY PARTS

CAB C-4  
Windshield CW-C4  
Door Window GDW-C  
Rear Fixed GRF-c Sliding GRS-C

Body Parts Cont'd.

Grab Handle HG-36

Rear View Mirror 9000

FENDER F-16

HOOD Hinged

Battery Box-DC-5A

MUNING BOARD ER-8

GAD HARDWARE - R.H. Door Lock 65-R Handle 330

L.H. Door Lock 65-L Handle 331

Window Regulator 85-24

Door Striker Plate 5623-A

Dove Tail Male A-247

Female A -246

Check strap 268-F

HOOD HARDWARE

Hood Handle 575

Hood Hooks 750044

Bracket 750500

MISCELLANEOUS

Water Tank WT-10

Sump Location Bottom L.H. Side

Filler Neck Located on each end of tank

Subframe SF-6D

U Bolts SUB-6

Pintle Hook 290

Draw Bar CR-2D

Paint Patrol Yellow

FIFTH WHEEL FW-6

Collar SX-10

Lock Jaw - LF-2

Nut - NF-32-8

Jaw Pins PI-11

Jaw Spring SC-9

LOCKING HANDLE SPRING SC-22

Hinge Pin

Locking Handle Springs Cont'd.

Bushings

LIFT FRAME SF-6D

Hinge Pin P x 4

bushing BR 16-32

Collar SA-19

Nut WF-32-8

LIFT CYL'D CT6-12-8

Box SBT-2

POWER TAKE OFF - PT-HY41K-78 C 4

MUNCIE PUMP HP-200SF 7/8 - 10

SELECTOR VALVE - CM3-06 R.T.D.L.

Front Axle

Brake Shoes A-37-3222-B-210  
Backing Plates A-1-3236-A-703  
Springs S-15 & S-15-1

Rear Axle:

Springs S-28 U-Bolts UB-12-C

Engine:

Jacobs Brake

Parking Brake

Type 30-30 Anchor Lock

Air Brakes:

One Relay Check Valve 225595

Steering:

Hydraulic Booster S-20-N-BX-22  
Flow Control Valve FM-3-08-P-060-100-10-

Paint:

Yellow 230

Body:

Lift Frame Assy. 993-M  
5th Wheel FW-12

SUPPLEMENT TO RACIFIC MODEL 4640-A  
SERIAL T-860-114